

OILFLAM 700.1 PR
OILFLAM 800.1 PR
OILFLAM 1000.1 PR
OILFLAM 1200.1 PR



Technical data



Operating instructions



Electric diagrams



Spare parts list



420010513700

OILFLAM 700.1 PR TC 230-400-50

OILFLAM 800.1 PR TC 230-400-50

3142127


OILFLAM 1000.1 PR TC 230-400-50

OILFLAM 1200.1 PR TC 230-400-50

APPENDIX

Spare parts

OILFLAM 800.1 PR



APPENDIX

Spare parts list

N°	DESCRIPTION		OILFLAM 800.1 PR code
1	PUMP	SUNTEC TA5C30106	65322993
2	HEATING ELEMENT PUMP	50 W	65323072
3	HOSES	25 x1500	65323181
4	COIL	EL011	65323809
5	CONETTORE BOBINA	EL011	65324809
6	MANOMETER	CEWAL R1/4 D50	65324105
7	COVER		65324059
8	GLASS		65320487
9	PEEP WINDOW FRAME		65320488
10	MOTOR	18500 W	65325248
11	CONTROL BOX BASE	LANDIS LAL2.25	65320097
12	CONTROL BOX	LANDIS LAL2.25 Tv22"	65320063
13	RELAY	FINDER 5532 8	65323139
14	RELAY BASE	FINDER 5532 8	65323149
15	REMOTE CONTROL SWITCH	AEG LS11K.00(1)	65323135
		AEG LS15K.00(2)	65323136
16	REMOTE CONTROL SWITCH	AEG LS4K.00(2)	65323133
		AEG LS7K.10(1)	65324097
17	MOTOR THERMAL RELAY	AEG B18K-260 21-26A	65324066
18	ANTI JAMMING FILTER		65323170
19	ADJUSTMENT OF FUEL TEMPERATURE	GEFRAN 600	65322045
20	MAIN SWITCH	cod.40100I1509	65324098
21	MANUAL / AUTOMATIC Selector		65323063
22	RESET SWITCH		65324101
23	FUSE HOLDER		65324279
24	LAMP	LYVIA 10X28 BA9S	65324100
25	AUXILIARY SWITCH HEATER		65324278
26	IGNITION TRANSFORMER	BRAHMA T8	65323222
27	PHOTORESISTOR	LANDIS	65320076
28	FAN	RU-560 M d.42	65324063
29	AIR CONVEYOR		65320648
30	RING		65320646
31	COVER AIR INLET		65324065
32	AIR DAMPER MOTOR	SQM50.481A2	65322902
33	THERMOCOUPLE	TC6MD2JBC	65322046
34	FILTER	U21008/01	65323158
35	HEATER	30 kW	65323091
36	OIL TANK		65324481
37	CABLE		65320947
38	RING		65321721
39	HOLDER SPRING		65321720
40	FIRING HEAD		65321722
41	PIPE		65324267
42	ROD FIRING HEAD	TC	65324579
43	ROD NOZZLE HOLDER	TC	65324269
44	HOLDER WAISTBAND		65324577
45	WAISTBAND		65324578
46	ELECTRODES		65325004
47	SUPPORT NOZZLE HOLDER		65320697
48	NOZZLE HOLDER		65320709
49	NOZZLE		
50	DIFFUSER		65320788

TC = SHORT HEAD TL = LONG HEAD

APPENDIX

Spare parts list

N°	DESCRIPTION		OILFLAM 800.1 PR
			code
51	BLAST TUBE		65324981
52	BLAST TUBE END		65325129
53	ASSEMBLY FIRING HEAD	TC	65322499
54	GASKET		65321137
55	GASKET		65321138
56	GASKET		65321139
57	SILENCER		65324071
58	FILTER	70501/03	65324103
59	ROD		65321468
60	COUPLING (FAN)		65321792
61	UNION (FAN)		65321791
62	COUPLING		65321790
63	COUPLING		65321782
64	UNION (PUMP)		65321786
65	COUPLING (PUMP)		65325219
66	GAS VALVE	BRAHMA EG12SRGMO	65323595
67	COIL	BRAHMA EG12S	65323709
68	GAS VALVE	BRAHMA EG12SRGMO	65323595
69	COIL	BRAHMA EG12S	65323709
70	AIR PRESSURE SWITCH		65323033
71	PREHEATED'S AUX. RESISTOR HOLDER		65321716
72	FIXING PLATE		65321717
73	HEATING ELEMENT	50 W	65323072
74	THERMOSTAT	IMIT TR2 40/200	65323147
75	HEATING ELEMENT	30 W	65324207
76	TIMER		65324073
77	ADJUSTMENT OIL PRESSURE	B-P-PRO-2 a.070H0115	65323167
78	OIL CAM GROUP		65322356
79	CHECK VALVE	ART. FZVR13 1-2	65325173

TC = SHORT HEAD TL = LONG HEAD