



BRUCIATORI DI GAS AD ARIA SOFFIATA  
BLOWN AIR GAS BURNERS  
BRULEURS GAZ A AIR SOUFFLE  
QUEMADORES DE GAS DE AIRE SOPLADO



# Ecoflam



BLU 500.1 P AB

BLU 700.1 P AB

BLU 1000.1 P AB

BLU 1400.1 P AB

Low Nox

G20-G25


G30-G31



LB1584

04.07.2006

**BLU 500.1 P AB**  
**BLU 700.1 P AB**  
**BLU 1000.1 P AB**  
**BLU 1400.1 P AB**  
 G20 / G25 - G30 / G31



| DESCRIPTION                |                        | BLU 500.1 P AB<br>code | BLU 700.1 P AB<br>code |
|----------------------------|------------------------|------------------------|------------------------|
| 1 - AIR PRESSURE SWITCH    | DUNGS LGW10 A2P        | Q120                   | Q120                   |
| 2 - AIR INTAKE SET         |                        | GRPA101                | GRPA101                |
| 3 - PLUG WIELAND           | 6 pin                  | E226                   | E226                   |
| 4 - BURNER COVER           |                        | BFC09151/011           | BFC09151/011           |
| 5 - GLASS                  |                        | BFC02004               | BFC02004               |
| 6 - PEED WINDOM FRAME      |                        | BFC02006               | BFC02006               |
| 7 - MOTOR                  | 550 W                  | M169                   | -                      |
|                            | 740 W                  | -                      | M147/4                 |
| 8 - FAN                    | 220 x 98               | BFV10155/001           | -                      |
|                            | 250 x 84               | -                      | BFV10153/001           |
| 9 - AIR CONVEYOR           |                        | BFC08202/017           | BFC08201/017           |
| 10 - FAN SCOOP             |                        | BFC08055/001           | BFC08051/001           |
| 11 - AIR INTAKE            |                        | BFC04160/011           | BFC04160/011           |
| 12 - CONTROL BOX BASE      | LANDIS                 | A402                   | A402                   |
| 13 - CONTROL BOX           | LANDIS LGB 22          | A130/1                 | A130/1                 |
| 14 - IGNITION TRANSFORMER  | COFI 820 PM            | T106/4                 | T106/4                 |
| 15 - REMOTE CONTROL SWITCH | TRIP. BG0910A          | R623                   | R623                   |
| 16 - MOTOR THERMAL RELAY   | Lovato RF9 1,4-2 ,3A   | R510                   | -                      |
|                            | Lovato RF9 2-3,3 A     | -                      | R510/1                 |
| 17 - MAIN SWITCH           | cod.40100I1509         | R1020                  | R1020                  |
| 18 - HIGH-LOW FLAME SWITCH | cod.360000001          | R1020/1                | R1020/1                |
| 19 - LAMP                  | EL/N-SC4 Elettrospring | E1510                  | E1510                  |
| 20 - FUSE SUPPORT          | FUSIT FH-B528          | E802/2                 | E802/2                 |
| 21 - IONIZATION CABLE      | TC                     | BFE01403/4             | BFE01403/4             |
|                            | TL                     | E1102/21               | E1102/21               |
| 22 - IGNITION CABLE        | TC                     | BFE01402/1             | BFE01402/1             |
|                            | TL                     | BFE01402/2             | BFE01402/3             |
| 23 - IONIZATION PROBE      |                        | BFE01075               | BFE01075               |
| 24 - IGNITION ELECTRODES   |                        | BFE01076               | BFE01076               |
| 25 - PRESSURE GAUGE        |                        | BFT01105/001           | BFT01105/001           |
| 26 - HEAD SUPPORT PIPE     |                        | BFT13121/004           | BFT13121/004           |
| 27 - HEAD PIPE             | TC                     | BFT13128/001           | BFT13128/001           |
|                            | TL                     | BFT13132/001           | BFT13132/001           |
| 28 - FIRING HEAD           |                        | BFT13118/051           | BFT13118/051           |
| 29 - HEAD CAP              |                        | BFT13119/051           | BFT13119/051           |
| 30 - DIFFUSER              |                        | BFT13133               | BFT13134               |
|                            | (G30-G31)              | -                      | BFT13133               |
| 31 - TOOTH                 | (G20)                  | BFT13120               | BFT13120               |
|                            | (G30-G31)              | BFT13126               | BFT13126               |
| 32 - FRONT DISC            |                        | BFD07043               | BFD07043               |
| 33 - ROD                   | TC                     | BFA08039/001           | BFA08039/001           |
|                            | TL                     | BFA08045/001           | BFA08045/001           |
| 34 - INNER ASSEMBLY        | TC                     | GRTT0102/001           | GRTT0102/011           |
|                            | (G30-G31) TC           | GRTT0102/003           | GRTT0102/013           |
|                            | TL                     | GRTT0102/002           | GRTT0102/012           |
|                            | (G30-G31) TL           | GRTT0102/004           | GRTT0102/014           |
| 35 - BLAST TUBE            | TC                     | BFB04018/017           | BFB04017/017           |
|                            | TL                     | BFB04022/017           | BFB04021/017           |
| 36 - GASKET ISOMART        |                        | BFG03002/1             | BFG03002/1             |
| 37 - ANTIJAMMING FILTER    |                        | S132/4                 | S132/4                 |
| 38 - AIR DAMPER MOTOR      | LANDIS SQN 30.151A2700 | M212/3                 | M212/3                 |

TC = SHORT HEAD TL = LONG HEAD

| DESCRIPTION                |                        | BLU 1000.1 P AB<br>code | BLU 1400.1 P AB<br>code |
|----------------------------|------------------------|-------------------------|-------------------------|
| 1 - AIR PRESSURE SWITCH    | DUNGS LGW10 A2P        | Q120                    | Q120                    |
| 2 - AIR INTAKE SET         |                        | GRPA101                 | GRPA101                 |
| 3 - PLUG WIELAND           | 6 pin                  | E226                    | E226                    |
| 4 - BURNER COVER           |                        | BFC09151/011            | BFC09151/011            |
| 5 - GLASS                  |                        | BFC02004                | BFC02004                |
| 6 - PEED WINDOM FRAME      |                        | BFC02006                | BFC02006                |
| 7 - MOTOR                  | 1100 W                 | M115/3                  | -                       |
|                            | 2200 W                 | -                       | M167                    |
| 8 - FAN                    | 260 x 98               | BFV10152/001            | -                       |
|                            | 260 x 110              | -                       | BFV10151/001            |
| 9 - AIR CONVEYOR           |                        | BFC08201/017            | BFC08201/017            |
| 10 - FAN SCOOP             |                        | BFC08051/001            | BFC08051/001            |
| 11 - AIR INTAKE            |                        | BFC04160/011            | BFC04160/011            |
| 12 - CONTROL BOX BASE      | LANDIS                 | A402                    | A402                    |
| 13 - CONTROL BOX           | LANDIS LGB 22          | A130/1                  | A130/1                  |
| 14 - IGNITION TRANSFORMER  | COFI 820 PM            | T106/4                  | T106/4                  |
| 15 - REMOTE CONTROL SWITCH | TRIP. BG0910A          | R623                    | R623                    |
| 16 - MOTOR THERMAL RELAY   | Lovato RF9 3-5 A       | R510/2                  | -                       |
|                            | Lovato RF9 4,5 - 7,5 A | -                       | R510/3                  |
| 17 - MAIN SWITCH           | cod.40100I1509         | R1020                   | R1020                   |
| 18 - HIGH-LOW FLAME SWITCH | cod.360000001          | R1020/1                 | R1020/1                 |
| 19 - LAMP                  | EL/N-SC4 Elettrospring | E1510                   | E1510                   |
| 20 - FUSE SUPPORT          | FUSIT FH-B528          | E802/2                  | E802/2                  |
| 21 - IONIZATION CABLE      | TC                     | BFE01403/4              | BFE01403/4              |
|                            | TL                     | E1102/21                | E1102/21                |
| 22 - IGNITION CABLE        | TC                     | BFE01402/1              | BFE01402/1              |
|                            | TL                     | BFE01402/3              | BFE01402/3              |
| 23 - IONIZATION PROBE      |                        | BFE01075                | BFE01075                |
| 24 - IGNITION ELECTRODES   |                        | BFE01076                | BFE01076                |
| 25 - PRESSURE GAUGE        |                        | BFT01105/001            | BFT01105/001            |
| 26 - HEAD SUPPORT PIPE     |                        | BFT13121/004            | BFT13121/004            |
| 27 - HEAD PIPE             | TC                     | BFT13128/001            | BFT13130/001            |
|                            | TL                     | BFT13132/001            | BFT13131/001            |
| 28 - FIRING HEAD           |                        | BFT13118/051            | BFT13118/051            |
| 29 - HEAD CAP              |                        | BFT13119/051            | BFT13119/051            |
| 30 - DIFFUSER              |                        | BFT13134                | BFT13136                |
|                            | (G30-G31)              | BFT13135                | BFT13135                |
| 31 - TOOTH                 | (G20)                  | BFT13120                | BFT13120                |
|                            | (G30-G31)              | BFT13126                | BFT13126                |
| 32 - FRONT DISC            |                        | BFD07045                | BFD07046                |
| 33 - ROD                   | TC                     | BFA08039/001            | BFA08047/001            |
|                            | TL                     | BFA08045/001            | BFA08048/001            |
| 34 - INNER ASSEMBLYA       | TC                     | GRTT0102/021            | GRTT0102/031            |
|                            | (G30-G31) TC           | GRTT0102/023            | GRTT0102/033            |
|                            | TL                     | GRTT0102/022            | GRTT0102/032            |
|                            | (G30-G31) TL           | GRTT0102/024            | GRTT0102/034            |
| 35 - BLAST TUBE            | TC                     | BFB05013/017            | BFB05012/017            |
|                            | TL                     | BFB05017/017            | BFB05016/017            |
| 36 - FLANGIA ISOMART       |                        | BFG03002/2              | BFG03002/2              |
| 37 - ANTIJAMMING FILTER    |                        | S132/4                  | S132/4                  |
| 38 - AIR DAMPER MOTOR      | LANDIS SQN 30.151A2700 | M212/3                  | M212/3                  |

TC = SHORT HEAD TL = LONG HEAD